

precision**PLAY**

MODEL: OS48130REY

NAME: PRECISIONPLAY STOP NET

ASSEMBLY INSTRUCTIONS



ASSEMBLY TIPS:

- 1 - Please read the instructions carefully, and follow all assembly, operation or safety instructions properly in order to avoid damage or injury.
- 2 - Some figures or drawings may not look exactly like your product. Please read and understand the text before beginning each assembly step.

NOTICE!

- 1 - Check All Contents Are Included Before Assembly.
- 2 - Always Assemble And Disassemble The Product Under Adult Supervision.
- 3 - Check The Equipment Before Each Time Use It.
- 4 - Any Breakage Found On The Product, Please Stop Assembling Or Disassembling It.











WARNING: Adult Assembly Required.



WARNING:

CHOKING HAZARD -- This item contains small parts. Not suitable for children under 3 years.

PARTS LIST

1  (2pcs)	2  (1pc)	3  (2pcs)
4  (4pcs)	5  (2pcs)	6  (1pc)
7  (4pcs)	8  (1pc)	

ASSEMBLY INSTRUCTIONS

FIG.1




FIG.2




FIG.3




FIG.4




FIG.5




FIG.5-1





FIG.5-2

YOU ARE NOW READY TO PLAY!